


Contents

	Page
Set contents	2
Cascade kit R40	3
Cascade kit R600	5


Contents



		#
A		1
B		2
C		2

Cascade kit R40

Assembly




Programming

Parameters

Boiler 1	Boiler 2	Boiler 3	Boiler 4	
<u>6600</u> : 1	<u>6600</u> : 2	<u>6600</u> : 3	<u>6600</u> : 4	
<u>6601</u> : 0	<u>6601</u> : 0	<u>6601</u> : 0	<u>6601</u> : 0	→ etc.


Cascade kit R40

Wiring




Cascade kit R600

Assembly



Programming

Parameters

Boiler 1	Boiler 2	Boiler 3	Boiler 4	
$\underline{6600} : 1$	$\underline{6600} : 2$	$\underline{6600} : 3$	$\underline{6600} : 4$	 etc.
$\underline{6601} : 0$	$\underline{6601} : 0$	$\underline{6601} : 0$	$\underline{6601} : 0$	

Cascade kit R600

Wiring

