


AcornVac Wastewater Collection System

How does it work?



- Each refrigerated or freezer case generates condensate which flows into the ACCUMULATOR or collection box located behind or below the case.
- When the condensate reaches a pre-determined level in the Accumulator, the CONTROLLER triggers the:
- EXTRACTION VALVE (X-Valve) allowing vacuum to evacuate the collected condensate into the vacuum main and then into the VACUUM COLLECTION CENTER (Vac Center).